

## Vemcall Quick Guide (SE)

Systemet är klart för användning vid leverans.  
Strömsätt laddtorn och sändare.

Lägg alla puckarna i laddtornet för laddning, efter en stund kommer numret på pucken fram i displayen.  
Puckarna ska ladda **minst** en timme innan användning, men helst 8 timmar för att vara helt uppladdade.

Puckarna tas ut från botten av laddtornet och läggs tillbaka på toppen efter användning.  
När en puck tas ur laddtornet blinkar den i 4 sekunder, därefter är den redo för användning.

Notera vilken puck som används till en viss order.  
När ordern är klar, tryck in pucknummer på sändaren och tryck på SEND.

T.ex. ordern för puck 16 är klar, tryck 16-SEND.  
T.ex. ordern för puck 1 är klar, tryck 1-SEND.

Pucken kan programmeras för att bara vibrera, bara blinka eller bara pipa, se nästa sida för dessa inställningar.

# VEMCALL QUICK GUIDE

## Plug & Play Installation.

Connect the power supply to both transmitter and charger.

Connect the power supply to 230V.

Place all pagers in the charger.

A number will show in the display on the pagers.

Charge the pagers min. 1 hour.

To be fully charged we recommend min. 4 hours.

Pagers are taken from the bottom of the charger.

The lights on the top of the pager will flash, when taken out of the charger.

The light stops after a few seconds.

Before giving the pager to the customer you must register the number of the pager.

Use the transmitter to call the pager.

Dial the number of the pager you want to call.

Ex. if you want to call pager number 1, press "1" on the transmitter and press SEND.

Ex. if you have to call pager number 12, press "12" on the transmitter and press SEND.

After use, return the pagers to the charger.

The pagers has to be placed with the logo facing upwards.

If there is any need for support, please contact your local reseller or send an email to [info@vemcali.com](mailto:info@vemcali.com)

## Change numbers on the pagers:

Place one pager in the charger. Fx pager number 1.

Use the transmitter.

Press "1 ENTER \*002 SEND". Now the pager will change to number 2.

If you want to change pager number 2 to number 3, press "2 ENTER \*003 SEND" etc.

If the pagers don't react to the command, lift the bottom pager in the charger for 2 seconds and try again.

## Settings for Vibration, Flash and Light in the pagers:

(Air Message operation. (Transmitter)

All pagers have to be active - NO POWER ON THE CHARGER!

Vibration only: Press "911 ENTER \*01 SEND"

Sound and Flash: Press "911 ENTER \*02 SEND"

Vibration and Flash: Press "911 ENTER \*03 SEND"

Flash only: Press "911 ENTER \*04 SEND"

Vibration, Sound and Flash: Press "911 ENTER \*05 SEND"

## Settings for Alert time (How long the pagers will sound/flash/vibrate):

8 sec. Press "911 ENTER \*11 SEND"

15 sec. Press "911 ENTER \*12 SEND"

30 sec. Press "911 ENTER \*13 SEND"

60 sec. Press "911 ENTER \*14 SEND"

120 sec. Press "911 ENTER \*15 SEND"

180 sec. Press "911 ENTER \*16 SEND"

Until back in charger: Press "911 ENTER \*19 SEND"

## Set pager to Sleep mode:

Press "911 ENTER \*99 SEND"